

Jumper Settings for M06194 PPU Board

Please refer to the below chart for the proper jump jack settings:

| Jumper | Grade 1 | Grade 2 | Grade 3 | Grade 4 | Grade 5 | Grade 6 | Unused |
|------------|---------|---------|---------|---------|---------|---------|--------|
| JXX | Out | In | Out | In | Out | In | Out |
| JXX | Out | Out | In | In | Out | Out | In |
| JXX | Out | Out | Out | Out | In | In | In |

IMPORTANT

If there are any unused positions on the board ensure that you have the jumpers in the *Unused* orientation. Leaving all jump jacks off will id Grade 1.

***** DO NOT LEAVE All Jump Jacks Out *****

Example:

Grade 1

Unused Position

